

Encoder



[LT#:A.E.05.03.0301](#)

45mm/4 pins 4 wires
Used for AC Motor

Encoder



[LT#:A.E.05.03.0302](#)

35mm/4 pins 4 wires
Used for AC Motor

Encoder



[LT#:A.E.05.03.0304](#)

45mm/4 pins 4 wires
Used for AC Motor

Encoder



[LT#:A.E.05.03.0305](#)

35mm/4 pins 4 wires
Used for AC Motor

Speed Sensor



[LT#:A.O.01.1005](#)

1036-0002
Used for Hangcha/Noblelift

Acceleration Sensor



[LT#:LL15-A001G](#)

29440-2K000/LE11-252A
Used for Nissan

Acceleration Sensor



[LT#:LL15-C003G](#)

FB-7(281E5-20403)
Used for Tcm

Speed Sensor



[LT#:LL15-C005G](#)

16402-54331
Used for Tcm

Speed Sensor



[LT#:LL15-C007G](#)

271A2-62101
Used for Tcm

Speed Sensor



[LT#:LL15-C008G](#)

281E5-22601
Used for Tcm

Speed Sensor



[LT#:LL15-C009G](#)

27B02-62201
Used for Tcm

Speed Sensor



[LT#:LL15-D001G](#)

D553110/12E-13
Used for Doosan

Motor Sensor



[LT#:LL15-J001G](#)

51009804
Used for Jungheinrich

Speed Sensor



[LT#:LL15-L002G](#)

3513604701
Used for Linde

Sensor



[LT#:LL15-L004G](#)

7917415537
Used for Linde

Potentiometer



[LT#:LL15-L007G](#)

7916400159/LE11-601A
Used for Linde


Potentiometer



[LT#:LL15-L008G](#)

7917415538
Used for Linde

Acceleration Sensor



[LT#:LL15-N001G](#)

QP-3HB-210-03
Used for Nichiyu

Acceleration Sensor



[LT#:LL15-N003G](#)

24300-44230
Used for Nichiyu

Acceleration Sensor



[LT#:LL15-N004G](#)

38920-00780
Used for Nichiyu

Acceleration Sensor



[LT#:LL15-N005G](#)

70000-44940
Used for Nichiyu

Acceleration Sensor



[LT#:LL15-N006G](#)

70000-57470
Used for Nichiyu Tractor

Speed Sensor



[LT#:LL15-S002G](#)

1407483002300/LE11-711A
Used for Shinko

Speed Sensor



[LT#:LL15-T001G](#)

14180-13900-71
Used for Toyota

SPEED SENSORS

01
PART

CONTROL SYSTEM PARTS

Speed Sensor



LT#:LL15-T002G

Used for Toyota

Speed Sensor



LT#:LL15-T004G

Used for Toyota

Accelerator Sensor



LT#:LL15-Z001G

Used for Sumitomo

CONTROL SYSTEM PARTS

LIFT/STEERING SENSORS

Lifting speed regulation sensor



LT#:A.O.01.0001

Used for Heli

Lifting speed regulation sensor



LT#:A.O.01.0010

Used for Heli/Tcm/Nichiyu

Lifting speed regulation sensor



LT#:A.O.01.0011

Used for Baoli

Lifting speed regulation sensor



LT#:A.O.01.0012

Used for Mima

Lift Sensor



LT#:LL16-C102G

Used for Tcm

Sensor



LT#:LL16-C103G

BP-ML-6619
Used for Tcm

LIFT/STEERING SENSORS

01
PART

CONTROL SYSTEM PARTS

Lift Sensor



LT#:LL16-J101G

Used for Jungheinrich

Lift Speed Sensor



LT#:LL16-L101G

Used for Linde

Sensor



LT#:LL16-N101G

Used for Nichiyu

Sensor



LT#:LL16-S101G

Used for Shinko

Sensor



LT#:LL16-S102G

Used for Shinko

Sensor



LT#:LL16-T102G

Used for Toyota

Potentiometer



LT#:A.O.01.0014

Used for Heli

Potentiometer



LT#:A.O.01.0020

Used for Heli

Sensor



LT#:A.O.01.0033

Used for Byd

Sensor



LT#:B.C.05.0101A1-2

91-MM-003A
Used for Liftstar

Sensor



LT#:B.C.05.0201A1

Used for Hangcha

Encoder



LT#:B.D.05.0103

91-MM-004A
Used for Liftstar

Encoder



[LT#:B.D.05.0201A1](#)

TVI40N-09TK2T6TN-00100
Used for Hangcha

Encoder



[LT#:B.D.05.0507](#)

64 Bit Encoder
Used for Xilin

Encoder



[LT#:B.D.05.0906](#)

256 Bit Encoder
Used for Jac

Steering Sensor



[LT#:LL17-A301G](#)

Used for Nissan

Direction Sensor



[LT#:LL17-C202G](#)

Used for Tcm

Turn/Direction Sensor



[LT#:LL17-C302G](#)

Used for Tcm

Steering Sensor



[LT#:LL17-C303G](#)

Used for Tcm

Steering Relay



[LT#:LL17-C304G](#)

G7L-2A-T/48V
Used for Tcm

Steering Relay



[LT#:LL17-C305G](#)

Used for Tcm

Direction Sensor



[LT#:LL17-H201G](#)

Used for Hyster

Direction Sensor



[LT#:LL17-J201G](#)

Used for Jungheinrich

Potentiometer



[LT#:LL17-K203G](#)

Used for Komatsu

Potentiometer



[LT#:LL17-L201G](#)

Used for Linde

Potentiometer



[LT#:LL17-L202G](#)

Used for Linde

Direction Sensor



[LT#:LL17-L204G](#)

Used for Linde

Steering Encoder



[LT#:LL17-L301G](#)

Used for Linde

Potentiometer Assembly



[LT#:LL17-L302G](#)

Used for Linde

Potentiometer Assembly



[LT#:LL17-L303G](#)

Used for Linde

Sensor



[LT#:LL17-L304G](#)

Used for Linde

Potentiometric Sensor



[LT#:LL17-L305G](#)

Used for Linde

Steering Sensor



[LT#:LL17-L306G](#)

Used for Linde


Sensor



[LT#:LL17-L310A](#)

Used for Linde

Potentiometer Repair Kit



[LT#:LL17-L401G](#)

Used for Linde

Electric Steering Sensor



[LT#:LL17-N201G](#)

Used for Nichiyu

Direction Sensor



[LT#:LL17-N203A](#)

Used for Nichiyu

Sensor



[LT#:LL17-N205A](#)

Used for Nichiyu

Direction Sensor



[LT#:LL17-S201G](#)

Used for Shinko

Direction Sensor



[LT#:LL17-T202G](#)

Used for Toyota

Direction Sensor



[LT#:LL17-T203G](#)

Used for Toyota

Direction Angle Sensor



[LT#:LL17-T205G](#)

Used for Toyota

Rear Axle Sensor



[LT#:LL17-T209G](#)

Used for Toyota

Rear Axle Sensor



[LT#:LL17-T210G](#)

Used for Toyota

Potentiometer



[LT#:LL17-T211G](#)

Used for Toyota

Steering Angle Sensor



[LT#:LL17-T303G](#)

Used for Toyota

Steering Sensor Cable Box



[LT#:LL17-T304G](#)

Used for Toyota

Direction Sensor Repair Kit



[LT#:LL17-T401G](#)

Used for Toyota

Crankshaft Position Sensor



[LT#:LL18-A501G](#)

Used for Nissan

Camshaft Position Sensor



[LT#:LL18-A502G](#)

Used for Nissan


Current Sensor



[LT#:LL18-C502A](#)

Used for Tcm/Toyota

Current Sensor



[LT#:LL18-L501G](#)

Used for Linde

Sensor



[LT#:LL18-L502G](#)

Used for Linde

Current Sensor



[LT#:LL18-N501G](#)

HC-TN500V28SP12
Used for Nichiyu

Sensor



[LT#:LL18-N502A](#)

NV-70F
Used for Nichiyu

Current Sensor



[LT#:LL18-N503G](#)

HC-TN700V35UP12
Used for Nichiyu

Front Wheel Brake Sensor



[LT#:LL18-T502G](#)

Used for Toyota

Sensor Assembly



[LT#:LL18-T504G](#)

Used for Toyota

Crankshaft Sensor



[LT#:C.H.04.0041](#)

Used for 4D32XG30

Camshaft Sensor



[LT#:C.H.04.0042](#)

Used for 4D32XG30